



PARTS MAP

Model: _____

Serial Number: _____

Notes: _____

Upper Casing Section


- 1 Hot Water Basin
- 2 XF Spray Nozzles
- 3 BACross III® Upper Fill with Integral Drift Eliminators
- 4 Axial Fan Assembly (see detailed view)
- 5 Fan Guard Assembly
- 6 Fan Cylinder
- 7 FRP Casing Panels

Lower Pan Section

- 8 BACross III® Lower Fill with Integral Drift Eliminators
- 9 Make-up Valve Assembly
- 10 Float Ball
- 11 Pan Strainer
- 12 Pan Strainer Hood
- 13 Internal Walkway
- 14 Access Door

Series 3000

Belt Drive Configuration
Cooling Tower





PARTS MAP

Model: _____

Serial Number: _____

Notes:

Upper Casing Section

- 1 Hot Water Basin
- 2 XF Spray Nozzles
- 3 BACross III® Upper Fill with Integral Drift Eliminators
- 4 Axial Fan and Bushing Assembly
- 5 ENDURADrive™ PM Motor
- 6 ENDURADrive™ ME Support
- 7 Fan Guard Assembly
- 8 Fan Cylinder
- 9 FRP Casing Panels


Lower Pan Section

- 10 BACross III® Lower Fill with Integral Drift Eliminators
- 11 Make-up Valve Assembly
- 12 Float Ball
- 13 Pan Strainer
- 14 Pan Strainer Hood
- 15 Internal Walkway
- 16 Access Door

Series 3000

Cooling
Tower

ENDURADrive™
Configuration



Find my BAC Rep to order parts, get maintenance tips,
and get a free unit inspection: www.baltimoreaircoil.com/RepFinder

Quantities may vary according to the unit. Applicable 2014-Present.



PARTS MAP

Model: _____

Serial Number: _____

Notes: _____


Upper Casing Section

- 1 Hot Water Basin
- 2 Spray Nozzles
- 3 BACross III® Upper Fill with Integral Drift Eliminators
- 4 Axial Fan Assembly (see detailed view)
- 5 Fan Guard Assembly
- 6 Fan Cylinder
- 7 FRP Casing Panels

Lower Pan Section

- 8 BACross III® Lower Fill with Integral Drift Eliminators
- 9 Make-up Valve Assembly
- 10 Pan Strainer
- 11 Pan Strainer Hood
- 12 Internal Walkway
- 13 Internal Walkway
- 14 Access Door

Axial Fan Assembly




- A Motor
- B Motor Coupling
- C Gear Coupling
- D Coupling Sleeve (not pictured)
- E Gear Box
- F Axial Fan and Bushing
- G ME Support
- H Motor Base (not pictured)

Series 3000

Gear Drive Configuration

Cooling Tower



Find my BAC Rep to order parts, get maintenance tips,
and get a free unit inspection: www.baltimoreaircoil.com/RepFinder

Quantities may vary according to the unit. Applicable 2014-Present.