



# PARTS MAP

Model: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Notes:

---

---

---

---

---

---

---

---

---

---

## Coil Module

- 1 Feed Box Assembly
- 2 Spray Branches
- 3 Spray Branch Header Grommets
- 4 Spray Branch Nozzle & Grommet
- 5 Coil Assembly  
\*\*The coil can only be replaced as a full coil module assembly
- 6 Drift Eliminators

## Lower Heat Transfer Section

- 7 Combined Inlet Shields
- 8 BACross II® Fill with Integral Drift Eliminators

## Fan Section

- 9 Fan Guard
- 10 Fan Cowl
- 11 Axial Fan Assembly *(see detailed view)*


## Pump and Pump Piping

- 12 Pump Assembly
- 13 Lower Pump Piping Assembly
- 14 Coupling and Clamp
- 15 Upper Pump Piping Assembly


## Pan Section

- 16 Make-Up Valve Assembly
- 17 Float Ball
- 18 Sump Strainer
- 19 Access Door
- 20 Internal Walkway

# FXV Closed Circuit Cooling Tower



### Axial Fan Assembly



- A Axial Fan
- B Fan Bushing
- C Fan Shaft
- D Bearing Kit
- E Mechanical Equipment Support
- F Motor Base and Adjustment Rod
- G Fan Motor
- H Motor Sheave
- I Motor Sheave Bushing
- J Fan Sheave
- K Fan Sheave Bushing
- L Belt Set



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: [www.baltimoreaircoil.com](http://www.baltimoreaircoil.com)